

# AlluGuard

style, security, innovation...

Installation  
sequence for Somfy  
Rollixo and Teleco



somfy



TELECO  
AUTOMATION

## INSTALLATION OF CONTROL PANEL

Action		
Attach control panel to wall		Use template
Next Step	Put control panel lid on	Leave control panel lid off
Set motor limits	Use external UP/DOWN buttons to run door up and down	Use internal PRG/DEL buttons to run door up and down
After motor limits	Press PRG Button	Hold down PRG/DEL button simultaneously until BEEP
If motor runs the wrong way	Hold down the stop button	Swap blue and black wires in terminal 5 & 7
Handset programming	Pre programmed in factory	Pre programmed in factory
Safety break	Wire into terminal blocks 5 & 6	Wire into terminal blocks 21 & 22
Safety edge programming	Press PRG button on control panel, and then press PRG button on BST	Hold down red button on radio card for 2 seconds. LEDs will flash. Press White button on BST. Return to radio card, and the blue LED will be on